

Installation Details For Quest Polar Activity Unit (QU01)

- 1 Construct base as per layout drawing P/QU01/01 ensuring the correct levels for safety surfacing.
- 2 Excavate 400mm x 400mm holes for Posts as in drawing P/QU01/02 to a depth of 500mm (800mm for loose fill) from finished safety surfacing height. (All Posts have finished ground level marks)
- Position the Posts as per drawing P/QU01/02.
 All posts are numbered.

 (Tan holes with a 10mm tan and make sure holts)
 - (Tap holes with a 10mm tap and make sure bolts are only hand tight at this stage)
- Fit the Posts in to the excavated holes and connect together using the various components as in drawing P/QU01/04 and the attached visual.
- 5 Excavate 400mm x 400mm holes for events as in drawing P/QU01/02 to a depth of 500mm (800mm for loose fill) from finished safety surfacing height.
- 6 Connect the events as per drawing P/QU01/04 using M10 x 30 resistorx & nylon washers.
- When installing the Climb Wall Panel to the top and bottom rail use the M10 x 50 resistorx bolts & plastic caps.
- 8 Once all equipment is fitted check levels again, check minimum dimensions as per drawing P/QU01/03, tighten all bolts and concrete in to the ground.























