

Installation Details For Quest Explorer Activity Unit (QU04)

- 1 Construct base as per drawing P/QUEXP/01 ensuring the correct levels for safety surfacing and minimum distances as detailed in P/QUEXP/SSD01.
- 2 Excavate 400mm x 400mm holes for Posts as in drawing P/QUEXP/02 to a depth of 500mm (800mm for loose fill) from finished safety surfacing height. (All Posts have finished ground level marks)
- Position the Posts as per drawing P/QUEXP/02. All posts are numbered.

 (Tap holes with a 10mm tap and make sure holts)
 - (Tap holes with a 10mm tap and make sure bolts are only hand tight at this stage)
- Fit the Posts in to the excavated holes and connect together using the various components as in drawing P/QUEXP/04 and the attached visual.
- 5 Excavate 400mm x 400mm holes for events as in drawing P/QUEXP/03 to a depth of 500mm (800mm for loose fill) from finished safety surfacing height.
- 6 Connect the events as per drawing P/QUEXP/04 using M10 x 30 resistorx & nylon washers.
- Assemble all other items of equipment as drawing P/QUEXP/04 using M10 x 30 resistorx & nylon washers.
- 8 Connect all ropes using the 8mm quick links & vandal pins.
- 9 Once all equipment is fitted check levels again, tighten all bolts and concrete in to the ground.

 Note: Do not leave unattended until satisfied the concrete has cured or the site is secure

























